



EXPANDED VIEW
VUE ÉCLATÉE
VISTA DETALLADA

INSTALLATION INSTRUCTIONS

Note 1: Prepare door, per additional Door Preparation instructions before installing unit.

Note 2: Refer to expanded view and illustrations to identify some parts.

Note 3: Programming instructions on reverse side.

A. Install Latch (a), Strike (b). 1. Determine your backset, see figure 1. 2. If required, adjust backset of latch as shown (see figure 2). 3. Install latch, securing with small wood screws (see figure 3). 4. Install strike with two 1-1/2" (38mm) wood screws (see figure 4).

B. Placing exterior cylinder assembly (c) on door. 1. Place cylinder assembly on door threading cable (d) under the latch (see figure 5). Make sure keyhole is positioned in the lower portion of cylinder face.

C. Installing mounting plate (e). 1. Angle the mounting plate (e) to accept the end of cable (d) through the slot (f) of mounting plate (see figure 6). With cable threaded through slot (f), position the plate over the 2-1/8" (54mm) hole (see figure 7). 2. Secure plate in place (e) with large screws, engaging exterior cylinder assembly (c) while keeping small holes of plate aligned with pilot holes previously drilled (see figure 8).

D. Preparing product: 1. Extend bolt (g) of latch with key from the exterior (see figure 9). 2. Rotate the turnpiece (h) of interior unit (i) so that the turnpiece opening (j) is in the lock position (with round of opening at top). (See figure 10.)

E. Attaching cable to connector (k) of interior unit (i). 1. Make sure the locking tab (l) of connector (k) is extended out from the connector body (m). (See figure 11.) Keeping cable (d) smooth and untwisted, insert end of cable between the locking tab (l) and connector body (m). 2. Depress the locking tab (l) to lock cable (d) into connector.

F. Mounting unit (i) onto door. (Refer to figure 12.) 1. Aligning turnpiece opening (j) with the torque blade (n) of cylinder assembly, press the unit flush against door (making sure the cable is safely tucked clear from pinching). 2. Keeping the unit vertically aligned, secure unit to door with three small wood screws (see figure 13).

G. Install 4 new AA Alkaline batteries (see figure 14) do not use rechargeable batteries. **Alkaline Battery Warning:** Do not: dispose of in fire, recharge, put in backwards, disassemble, mix with used or other battery types. May explode or leak and cause personal injury.

H. Proceed to PROGRAMMING on reverse side. Once unit is programmed, **install cover (p)** as follows: Aligning cover over unit and press cover down and on (see figure 15).

